

# APPENDIX A

## Recommended Replacement Intervals - Low Water Cut-offs

Series	Recommended Maintenance	Recommended Replacement Interval (max.)
*150, 150S *157, 157S *158, 158S *159, 159S 93, 193, 94, 194	Blow down and test daily; inspect annually	15 years
*42, 42S		10 years
67, 767, 61, 63, 64, 764	Blow down and test weekly; inspect annually	10 years
69, 169, 269, 369, 469, 569	Test and inspect annually	10 years
750, PS-800, PSE-800, PS-850, 750B, RB120, RB122E	Test and inspect annually	15 years
RB24E	Test and inspect annually	10 years
1575, 150E	Test daily and inspect annually	15 years

\*Mercury Units are no longer available.

## Replacement Head Mechanisms for Commercial/Industrial Applications

Series	Recommended Maintenance	Recommended Replacement Interval (max.)
*150-HD, 150S-HD, 93-HD, 94-HD, 42-HD, 42S-HD, 63-HD, 64-HD, 6667, 150E-HD	Test and inspect annually	15 years